



Wiring diagram 2nd version

- 1 Electronic interval rewiper backdoor
- 2 Wiper motor, backdoor
- 3 Washer pump, backdoor
- 4 Detent switch wiper motor backdoor  
Detent switch interval wiper, backdoor
- 5 Detent switch dome lamp rear  
Tipping switch washer pump, backdoor
- 6 8-point line connector above backdoor

- a Fuse terminal 15
- b To dome lamp rear
- M2 Main ground behind instrument cluster
- M8 Ground, luggage compartment wheelhouse right
- M9 Ground, backdoor (8-point line connector)